

Audit
Inventory
Service
Diagnostic
Settings
Filling

A Audit

General data
- Machine number
- Number of printouts/readouts
- Number of power resets
- Tube contents
- Recycler content

Vends
- Sales of all payment sources
- Cash sales
- Cashless sales
- Token sales
- Free vends
- Free vends with token
- Test vends
- Discounts
- Sales per selection line

Flow of money
- Coin data
  - Coins to cash-box
  - Coins to tube
  - Change paid out
  - Change paid out from Hopper
  - Coins to tube manual filling
  - Coin paid out manually
  - Cash overpay
  - Credited from machine
  - Coin counter
    - Counter: Accept
    - Counter: In tube
    - Counter: Paid out
- Bill data
  - Accepted bills
  - Bills to recycler
  - Bills paid out
  - Bills to recycler manually
  - Bills paid out manually
- Cashless data
  - Debited from cashless
  - Credited to cashless
  - Discounts from cashless
  - Token from cashless
- Token
  - Accepted tokens
  - Token overpay
  - Freevend token

B Inventory

Assignment, coin cassette

Change stock

Tube counters A-F

You may use inventory keys A-F to pay out tube coins

C Service

Show payout combination

Coin Management
- Payout statistic
- Status of analysis
- Proposals for optimization

Token Teach
- Token teach
  - Token A
  - Token B
  - Token C
- Token delete
  - Token A
  - Token B
  - Token C

Empty tubes

Hopper
- Hopper Inventory
- Hopper manual fill mode
- Reset Hopper counter

Airport ready -> send SMS

D Diagnostic

Validator module

Changer module

Payout module

Audit module

Display modul

Hopper

Motor sensors

Sensor left

Sensor middle

Sensor right

E Settings

p.t.o.

F Filling

Assignment, coin cassette

Change stock

Tube counters A-F

You may refill the cassette by inserting the tube coins

For more details about configuration and service work on the coin changer please refer to the c² Configuration and Service manual (www.cranepi.com, Support).

02.15 Schn/Roe
MS_c2_M_EN_1-3

Crane Payment Innovations GmbH | Zum Fruchthof 6 | D-21614 Buxtehude | Phone: +49 (0) 41 61-729-0 | Fax: +49 (0) 41 61-729-115 | E-mail: info@cranepi.com | www.cranepi.com



Settings

- Operating modes
  - Configure inventory keys
  - Security stock in the tubes
  - Security stock to VMC
  - Only tube coins in filling mode
  - Tube counter correction
  - Program tube counters automatically
  - Float-up
  - Tube counters correction to zero
  - Manual fill report
  - Simple payout
  - Tube coins two times in SETUP
  - Payout as change machine
- Inhibit mask
  - Inhibit coins (coins 1-16)
- Peripheral
  - Recycler
    - Communication with recycler
    - Inhibit bill acceptance
    - Empty recycler store
  - Hopper
    - Communication with hopper
    - Preferential hopper coins
    - No correction of Hopper counters
    - 12_ Coin value in Hopper 1
    - 12_ Coin value in Hopper 2
    - 12_ Coin value in Hopper 3
    - 12_ Coin value in Hopper 4
    - Hopper 1 sorted in path 2
- Coin settings
  - 12_ Filling level limitation (tubes A-F)
  - 12_ Security stock (tubes A-F)
  - Coin sorting
    - Select tube cassette
    - New payout combination
    - 12_ Spider-sorting
  - 12_ Security level (coins 1-16)
  - 12_ Float-Up counters (tubes A-F)
  - 12_ Float-Up tube contents
  - 12_ Setting of token value (Token A-C)
  - 12_ Condition for tube empty
- Other settings
  - 12_ Base coin value
  - Language
  - 12_ Currency code
  - MDB level
  - 12_ Display contrast
  - 12_ Wake-up time
  - Display
  - 12_ Decimal places
- Audit module
  - 12_ Machine number
  - Configurate audit interface
    - Time
    - Product-specific data
    - Sales data
    - Start button on printer
    - Printer format
    - IrDA high speed
    - Readout with bluetooth
  - 12_ Set system date
  - 12_ Set system time
- Airport
  - 12_ Message changer blocked (min)
  - 12_ Message for no coins (h)
  - 12_ 1. Telephone-No. SMS Receiver
  - 12_ 2. Telephone-No. SMS Receiver
  - SMS transmission options
    - SMS if changer inhibit by VMC
    - SMS if long time no coins accepted
    - SMS if door open
    - SMS if jam in the payout module
    - SMS if error in the validator
    - SMS if exact change status
    - SMS if vend value reached
    - SMS if low change
    - SMS if failure no longer exist
    - Keep alive SMS all 24h
  - 12_ Vend-value for sending a SMS
  - 12_ Value for low change SMS